



SECURITY - SURVEILLANCE - PEACE OF MIND

**For Tracking using SMS (recommended)**

1. Charge the Tracker Battery overnight.
2. Purchase a mobile Phone SIM. Make sure it's the large SIM from Vodafone.
3. Place the SIM in the Tracker
4. With your own phone text the Tracker ***begin123456***
5. You should receive a text message back from the Tracker ***begin ok***
6. Set up your phone as the administrator by texting the tracker ***admin123456 0876669186***  
replace 0876669186 with your own phone number.
7. Ready to go! You only need to do the above steps once after you purchase.
8. Call the Tracker anytime and you will receive a text reply with the time, date, speed and link. Click on the link and it will open Google maps automatically and shows the Tracker location on the Map.

---

**Move Alert:** You can setup the tracker to alert you once it moves outside a radius of circa 200 metres. Text the tracker ***move123456*** making sure the tracker is outside and stationary. You should receive a text ***move ok***.

Once the tracker goes outside this radius it will alert you with a text.

**Shock sensor Alarm:** You can setup the tracker to alert you when it is shocked. (if it is picked up and shaken) . This can be useful as a car alarm. i.e. if the car is tampered with or moved slightly causing the tracker to vibrate it will alert you with a text.

Text the tracker ***shock123456*** and you should receive a text ***shock ok***.

Once the tracker is shocked it will alert you with a text.

**Over speed alert:** You can setup the tracker to alert you when it goes over a specified speed.

Text the tracker ***speed123456 120*** to alert your phone when the tracker exceeds 120kmph. You can change to whichever speed alert suits your needs. It works best at speeds >60kmph.